


WHEELCHAIR ACCESSIBLE VEHICLES



Mercedes-Benz

Citan



Kangoo



Townstar



SPACIOUS, FLEXIBLE AND VERSATILE

A reliable family car with a wide range of seating options and optimal space and visibility for wheelchair passenger.

Conversion manual

Table of contents		
1	Disassembly	3
2	Exhaust disassembly	9
3	Fuel system disassembly	11
4	Marking the floor	13
5	Rear crossmember cut	14
6	Rear crossmember	17
7	Main floor cut	25
8	Suspension modification	27
9	Lowered floor	36
10	How to seal	41
11	Sealant	48
12	3-point belt preparation	51
13	TriflexAir seat bracket	55
14	Wiring	59
15	Floor LED preparation	67
16	Fuel system install	67
17	Exhaust install	75
18	Cavity protection coating	87
19	Bottom finished	87
20	Upholstery	88
21	Floor LED install	91
22	3-point belt stalks	94
23	Front retractors	95
24	Front cover	96
25	Finishing	97
26	Parking sensors	102
27	Interior panels	107
28	3-point belt install	110
29	Rear bumper support	112
30	Ramp	115
31	2nd row OEM seats	126
32	3rd row TriflexAir seats	127
33	Taillights	135
34	Rear bumper	135
35	Emergency exit	147
36	Tailgate cover protection	155
37	Rear retractors	158
38	End of conversion	158
39	Tightening torques	160
40	Tools & chemicals	161

IMPORTANT:


Keep all bolts & nuts!
The steps where tectyl, glue and some where sealant is used require time to dry. In the meantime it's possible to do some steps that do not intervene with the drying process. Disconnect the battery during the conversion. The parts that receive the tectyl treatment, must have the tectyl applied when mounted to the vehicle, NOT before.

Disassembly




Remove the tailgate panel.
Be sure to keep all of the clips.

Disassembly



Remove the rear sill and lashing eyes.

Disassembly



Remove the tailgate striker.

Disassembly



Take the seat out the rear of the vehicle.

Disassembly



Take out the floor mat.

Disassembly




Take out the interior panels and door rubbers.

Disassembly



Take out the top interior panels and door sills.
Pull aside the cables on the floor.

Disassembly



Remove the rear wheels and the right side wheelarch.

Disassembly



Remove the taillights, rear bumper and plastic covers. Move aside the keyless entry unit.

Disassembly


Modify the inner bumper the same way if it's prepared for a to hitch.

120 mm




Cut the inner bumper as shown.

Disassembly




Take off the inner bumper corners.

Disassembly




Take off the marked plastic covers.
Also remove the plastic cover on the rear axle. Don't keep this.

Exhaust Disassembly




Cut off and remove the rear muffler.

Exhaust Disassembly




Remove the rest of this pipe with the clamp.

Exhaust Disassembly




Remove the rear heatshield.
Keep the exhaust bracket for later.

Fuel system disassembly




Make sure the fuel tank is empty.
Take off the fuel tank shield+bracket and lower the fuel tank.
Disconnect the fuel lines and pull the breather hose aside.

Fuel system disassembly




Cut the fuel filler pipe as shown.

Fuel system disassembly



Take out the fuel element.



Fuel system disassembly




Remove the bolts on this side of the floor covers so the covers can be tilted down so the fuel lines are more easily reached.

The fuel lines can be disconnected here.

Remove the fuel lines.




Rear crossmember cut



Cut the first part of the floor as shown.

Rear crossmember cut

Remove this clip or use a hammer do flatten it.



Cut this flap off on both sides.

Rear crossmember cut


Remove this flap.

Remove the leftovers from this beam on both sides.


Rear crossmember cut

Drill the marked holes $\varnothing 10\text{mm}$ and thread M12.


Rear crossmember cut



Rear crossmember cut



Rear crossmember cut




Apply anti corrosion paint on all bare metal edges and surfaces.

Rear crossmember




On top of the rear crossmember:
Rethread the welded nuts on the mounting points.

Rear crossmember



Use a gearbox jack to put the crossmember in position.

Rear crossmember




Bag #19898

Mount the top of the crossmember.


NO.	QTY	PART	DESCRIPTION
1	4	1256	Hex bolt M10x30 8.8
2	4	173	Washer M10 8.8

Rear crossmember



Temporarily mount the rear side to secure correct position.
 Drill the marked holes $\text{\O}12\text{mm}$.
 Take the bolts out after drilling.

Rear crossmember



Bag #19898

Mount the LEFT side of the crossmember as shown.

NO.	QTY	PART	DESCRIPTION
1	2	824	Hex bolt M8x30 8.8
2	2	1246	Large washer M8 8.8

Rear crossmember

On the RIGHT side, drill the marked hole Ø10mm.

Rear crossmember

Route the flange nut through the beam, over the towing eye cylinder. Position over the just drilled hole. Mount with the bolt.


- 3
- 2
- 1

Bag #19898

NO.	QTY	PART	DESCRIPTION
1	1	1256	Hex bolt M10x30 8.8
2	1	181	Large washer M10x30x2.5 8.8
3	1	11339	Hex flange nut M10 10.9


Mount the RIGHT side as shown.

Rear crossmember



On the inner bumper corners:
Drill the marked holes up to Ø14mm.



Rear crossmember




Bag #19898

Place the OEM inner bumper corners on the crossmember. Mount the back of the crossmember.


NO.	QTY	PART	DESCRIPTION
1	6	11335	Hex bolt M12x30 10.9
2	6	7209	Large washer M12x36x3 8.8



Rear crossmember




Rear crossmember



NO.	QTY	PART	DESCRIPTION
1	2	11335	Hex bolt M12x30 10.9
2	4	288	Large washer M12x36x3 8.8
3	2	58	Torque nut M12 10.9

Rear crossmember




Bag #19898


On the left side there are 2 small threaded holes. This is where the keyless entry unit will be mounted. Mount as shown

NO.	QTY	PART	DESCRIPTION
1	2	10815	Socket button head screw M6x12 010.9
2	2	216	Washer M6 8.8

Rear crossmember




Main floor cut



Move the electric cables aside to prevent damage while cutting.



Main floor cut




Be sure to cut around the spring mounts.

Cut the second part of the floor.

The result should look like this!




Main floor cut




Use an air gun to blow all the metal chips out of the rear crossmember. Apply cavity protection coating inside the standing beams of the rear crossmember through the holes marked with the arrows.

Suspension modification




Dismount the lower shock absorber point.

Suspension modification



Take out the springs and bumpstops.


Suspension modification



Only in case of a ride height sensor!


If the vehicle is equipped with a ride height sensor it will be positioned on the left suspension arm. Take the sensor off of the arm before raising the ride height.

Suspension modification




Beforehand, mark the position of the OEM suspension bracket. This position is important later.

Suspension modification



ONLY ON ONE SIDE AT A TIME!
Remove the marked bolts.


Suspension modification



ONLY ON ONE SIDE AT A TIME!

Lower one side of the suspension.
Place the spacer between the bracket and the bottom of the vehicle.

Suspension modification




ONLY ON ONE SIDE AT A TIME!

Mount the bracket and spacer with the new bolts as shown.


Bag #19911

NO.	QTY	PART	DESCRIPTION
1	4	17275	Hex flange bolt M14x1,5x80 10.9
2	4	8576	Large washer M14x44x3


Suspension modification



Suspension modification




Suspension modification



Complete the past 6 steps on the other side as well.


Suspension modification



Only in case of a ride height sensor!

After raising the ride height, place the ride height sensor back on the suspension arm.

Suspension modification




Bag #19911

Mount the OEM bolt back here.


NO.	QTY	PART	DESCRIPTION
1	1	2009	Spacer di14/D25/L41

Suspension modification



Drill these holes Ø10mm.

Suspension modification




Bag #19911

NO.	QTY	PART	DESCRIPTION
1	2	9113	Hex bolt M10x25 8.8
2	4	173	Washer M10 8.8
3	2	63	Torque nut M10 8.8


Mount the bottom of the bracket as shown.

Suspension modification




Place the bumpstops, spring and new spacer on the rear axle as shown.

Suspension modification



Suspension modification




Bag #19911

NO.	QTY	PART	DESCRIPTION
1	1	17275	Hex flange bolt M14x1,5x80 10.9
2	1	229	Washer M14 8.8
3	1	17133	Torque nut M14x1.5 10.9


Mount the shock absorber to the new bracket.

Suspension modification




Torque the bolts as shown.

Lowered floor



Place the lowered floor in the vehicle.

Lowered floor




Bag #20573

Place the lowered floor in the vehicle.

NO.	QTY	PART	DESCRIPTION
1	4	7887	Magna-lock pop rivet 6,4x14 8.8



Lowered floor




Bag #19898

Mount hand tight, do not torque yet.

NO.	QTY	PART	DESCRIPTION
1	1	205	Hex bolt M8x16 8.8
2	1	1246	Large washer M8 8.8
3	1	9113	Hex bolt M10x25 8.8
4	2	9112	Large washer M10x33x2.5 8.8



Lowered floor




Bag #20573

Place these Magna-locks, do NOT mount them.


NO.	QTY	PART	DESCRIPTION
1	4	7887	Magna-lock pop rivet 6,4x14 8.8

Lowered floor



Drill the other holes Ø6,5mm.

Lowered floor




Bag #20573

Place the Magna-locks and fully mount them.
Also mount the previously placed Magna-locks.


NO.	QTY	PART	DESCRIPTION
1	17	7887	Magna-lock pop rivet 6,4x14 8.8

Lowered floor



Torque the bolts under the side of the vehicle.

Lowered floor



Use an angle grinder to remove all of the welding bumps on the floor.

How to seal



When applying sealant, first locate the edge or spot that needs sealant. Edges where 2 or more plates overlap each other or form a corner are an example. Also any spot where even a slight opening/gap from the outside to the inside of the vehicle or a closed beam is located.

How to seal




Degrease the surfaces that the sealant will be applied to.

How to seal



Position the sealant gun at the start of the edge.

How to seal



With a smooth and controlled motion, move the sealant gun along the edge to apply the sealant. Use the trigger with a controlled matter to create an even line of sealant.

How to seal




When done properly, the line of sealant should look like this. BEWARE, this is not the final step to properly seal.

How to seal



To properly seal, the sealant must be spread out evenly by using a sealant bush.

How to seal



Some people might prefer to cut the brush to a short size, this allows for more precise usage. This is not mandatory.

How to seal



Some people might prefer to cut the brush to a short size, this allows for more precise usage. This is not mandatory.

How to seal




Start spreading the sealant with the brush. Start at the beginning of the sealant line.

How to seal



First use the brush in one direction.

How to seal



When finished in direction one, use the brush back in the other direction. This way the sealant will spread evenly and its use will be optimized.

How to seal







Be sure to fully cover the edge/gap with sealant using the brush. If ALL edges and gaps have been covered, there should be no way possible for water to enter the vehicle where it could cause corrosion. Only then is has the sealant been applied properly.

How to seal




After sealing, wipe the sealant off the brush and place the brush in a cup with turpentine to get the sealant out of the brush.






Sealant




Using Sikaflex 221 white, seal every seam and gap where water could pass through.

It is VERY IMPORTANT to let the sealant dry overnight!
Only when the sealant is completely dry you can tectyl the chassis and the floor.
On the inside of the car: use tape to close EVERY hole/opening to protect the interior.
Tectyl the floor using:
- Tectyl Terotex HV450 in all hollow beams and compartments
- Tectyl Terotex aqua 3000 on the entire lowered floor
or 3M anti stone chill protection waterbaseblack 1L 08881




Do NOT work on the bottom of the car once tectyl has been applied until it's dry, wait about 24h. In the meantime, work on the interior/wiring/bumper etc.


3-point belt preparation



3-point belt preparation



3-point belt preparation




Bag #21626

Mount the threaded plate using the bolt and bushing. Make sure the threaded plate is positioned flat as shown.

NO.	QTY	PART	DESCRIPTION
1	1	8728	7/16 UNF treaded plate
2	1	19896	Spacer di12/D35/L30
3	1	4460	Hex bolt UNF 7/16 x 2,5"

3-point belt preparation




Bag #21626


Drill two Ø4mm holes left & right of the bushing. Mount two pop rivets to keep the threaded plate in position. Take the bolt and bushing out when the pop rivets are mounted.

NO.	QTY	PART	DESCRIPTION
1	2	3541	Pop rivet 4,0x18 st/st


3-point belt preparation



3-point belt preparation




3-point belt preparation



Drill the marked hole as shown.

3-point belt preparation




Place the threaded plate inside the D-pillar, aligned with the drilled hole. Use one of the 2 marked holes at the top right of the D-pillar to route the treaded okate as shown.

Bag #21626

NO.	QTY	PART	DESCRIPTION
1	2	20105	7-16 UNF threaded plate with double sided tape


3-point belt preparation



Bag #21626

Use the bolt to keep the threaded plate in place.

TriflexAir seat bracket



Place the TriflexAir seat bracket.

TriflexAir seat bracket


These holes are already in the lowered floor.
Align the holes in the bracket with these holes.

Place the TriflexAir seat bracket

TriflexAir seat bracket


Mark these holes on the floor.

TriflexAir seat bracket




Drill the holes Ø10mm.

TriflexAir seat bracket



Place the TriflexAir seat bracket.


TriflexAir seat bracket



Bag #21491

NO.	QTY	PART	DESCRIPTION
1	2	9113	Hex bolt M10x25 8.8
2	2	16282	Hex bolt M10x50 10.9
3	4	173	Washer M10 8.8


TriflexAir seat bracket



Bag #21491


NO.	QTY	PART	DESCRIPTION
1	2	11339	Hex flange nut M10 10.9
2	2	5635	M10 threaded plate

TriflexAir seat bracket




IMPORTANT!
 Make sure the mounting bracket is level! If adjustment is needed, Place shims to adjust the bracket, then torque the bolts. Afterwards re-check if it's still level.

Wiring



NO.	PART	DESCRIPTION
1	7454	Electric reels relais/wire loom
2	16487	Led lights relais/wire loom
3	16492	Led lights extention cable
4	16493	Led light
5	11594	Electric reels switch
6	3314	5 Amp fuse
7	95	10 Amp fuse
8	22186	LED light, side floor, 6 LEDs, wiring


Wiring



Connector with 12 poles

The trailer connector is located on the left side of the vehicle as shown. This is connected to fuse F28 in the fuse box on the driver side. This will be used to power the Tripod systems. Cut the red wire. Note: In some occasions there will be a different connector, one with 12 poles. This will be used in the same way.

Wiring



Fuse F28 is located here.

Wiring




Connect the Tripod supply wire where shown.



Wiring




Mount the relays with the included screws as shown.




Position the relays in this area as far down as possible between the wheelarch and the D-pillar.

Wiring




Connect the electric reel switch as shown. 1 of 3 pins on the switch is a different color. Make sure to connect the ground cable to that pin.

Wiring




Route the power supply line up and along (NOT THROUGH) the D-pillar and over the roof liner. Connect the wire to the relays.

Wiring




Route the LED wires from the relays, up along (NOT THROUGH) the D-pillar and over the roof liner to the other side.

Wiring




Route the LED wires through the square hole and out of the square hole in the rear crossmember. Do this on both sides.

Wiring




Apply cyanoacrylate glue (super/instant glue) to the back of the led housing and fix them to the crossmember using the square holes to position correctly.

Wiring




Pull the foil from the back of the led lights and position them centered in the housing on the crossmember.

Wiring




Connect the wires as shown.

Wiring




Wiring



Connect the wire from the magnetic switch to the relais.
Route the magnetic switch wire up on the side of the D-pillar.
Place the magnet above the roof liner, in the fabric.
Install the counter magnet on the tailgate, properly aligned
with the magnet on the roof liner.


Wiring



Apply the connectors to both ends as shown.


Route the front wires over the wheelarch as shown.
Place the connectors already in the right position for the retractor.

Floor LED preparation




Connect the floor LED wires to the remaining connector on the LED wires. Route the floor LED wires as shown with the purple line. Put the wires on the floor inside the vehicle. These will be fully installed later. Do this on both sides.

Fuel system install




Take the clips off the wire loom underneath the vehicle.


Fuel system install



Fuel system install




Fuel system install




Install the fuel element inside the new fuel tank.
Use the OEM O-ring.

Fuel system install



Fuel system install




Bag #21527

NO.	QTY	PART	DESCRIPTION
1	1	21552	Breather hose Ø17 inw L= 1452 mm
2	1	4225	Hose clamp ABA 12mm 15-24
3	1	3590	Hose clamp RSGU 25/15
4	1	10205	Torque nut M5 A2-70

Place the breather hose as shown.


Fuel system install



5Nm

Make sure the turn in the hose is as shown. This hose must not get stuck between the chassis and the tank while mounting.

Fuel system install




Bag #21527

NO.	QTY	PART	DESCRIPTION
1	1	21528	Fuel line 8x3 L=115 mm
2	1	18050	Clamp with inner ring 13,0-15,3
3	1	3545	Hose clamp RSGU 12/15
4	1	10205	Torque nut M5 A2-70

Install the small EVAP conduit on the small nipple as shown.

Fuel system install




Bag #21527

NO.	QTY	PART	DESCRIPTION
1	3	21554	Flue line clamp Ø8-10 mm

Place the fuel line clamps on the threaded studs.

Fuel system install




Bag #21527

Install the EVAP and fuel line as shown.


NO.	QTY	PART	DESCRIPTION
1	1	18050	Clamp with inner ring 13,0-15,3

Fuel system install



Raise the fuel tank in position with a gearbox jack. Be sure to connect the wire loom. Be absolutely sure there are no wires, lines or hoses getting stuck while mounting the tank.

Fuel system install




Bag #21527

Install a fuel line clamp on the fuel tank bracket.

NO.	QTY	PART	DESCRIPTION
1	1	16732	Socket button head screw M5x20 A2-70
2	1	10550	Hex nut M5 A2-70
3	1	21554	Fuel line clamp Ø8-10 mm



Fuel system install




Bag #21527

Raise the fuel tank in position with a gearbox jack


NO.	QTY	PART	DESCRIPTION
1	4	145	Hex bolt M8x20 8.8
2	4	1246	Large washer M8 8.8





Exhaust install




Exhaust install





Exhaust install



87 mm

Cut off the end pipe of the rear muffler as shown.

Exhaust install




100,00 Deg


90,00 Deg

Fold the exhaust heatshield as shown.

Exhaust install



Exhaust install




Bag #21007

Mount with a pop rivet.


NO.	QTY	PART	DESCRIPTION
1	1	7991	Pop rivet 4,0x12 alu/st
2	1	4	Large washer M4 4x20x1,25

Exhaust install



Fold the exhaust heatshield as shown.


Exhaust install



Apply the washer on the inside to cover the slotted hole.

NO.	QTY	PART	DESCRIPTION
1	2	7991	Pop rivet 4,0x12 alu/st
2	2	4	Large washer M4 4x20x1,25

Exhaust install




Bag #21007

Mount the stick-on heatshield to the outside of the metal heatshield. Apply the pop rivets to the holes in the surface of the metal heatshield.

NO.	QTY	PART	DESCRIPTION
1	4	7991	Pop rivet 4,0x12 alu/st
2	4	4	Large washer M4 4x20x1,25

Exhaust install




Bag #21007

Install the heatshield as shown.

NO.	QTY	PART	DESCRIPTION
1	1	145	Hex bolt M8x20 8.8
2	1	1246	Large washer M8 8.8

Exhaust install




Bag #21007

NO.	QTY	PART	DESCRIPTION
1	3	7991	Pop rivet 4,0x12 alu/st

Install the heatshield as shown.

Exhaust install




22Nm

This bolt was positioned on page 74.


Torque the bolts.

Exhaust install



Position the remainder of the OEM heatshield through the opening in the new heatshield. Check is the wire loom is still positioned correctly and not touching anything.

Exhaust install




Be sure the outside slit is positioned at the side.

Bag #21007

Mount the new exhaust pipe to the rear muffler as shown.

NO.	QTY	PART	DESCRIPTION
1	1	5258	Exhaust clamp Ø54,5

Exhaust install



Fully torque after the exhaust is in correct position.

Hang the rear muffler and exhaust pipe in the exhaust rubber and position correctly. Be sure the exhaust hangs free and does not touch anything.

Bag #21007


NO.	QTY	PART	DESCRIPTION
1	1	5258	Exhaust clamp Ø54,5

Exhaust install




Be sure the rear muffler doesn't touch the heatshield. With the muffler in correct position, mark the hole of the exhaust rubber bracket.

Exhaust install



Lower the exhaust and drill Ø13.5 mm.


Exhaust install



Bag #21007

NO.	QTY	PART	DESCRIPTION
1	1	10396	Flat head riveted nut M10x24 8.8

Exhaust install




Bag #21007

Put the exhaust back in position and mount the bracket.


NO.	QTY	PART	DESCRIPTION
1	1	9113	Hex bolt M10x25 8.8
2	1	181	Large washer M10 8.8

Exhaust install




48Nm

Exhaust install



Fully tighten the clamp.


Exhaust install



Bag #21007

NO.	QTY	PART	DESCRIPTION
1	1	9932	Starlock washer 12 mm

Cavity protection coating



The arrows indicate certain examples of where the coating is supposed to be applied.


Apply cavity protection coating in all hollow/open areas on the bottom of the conversion to prevent rust in the future. This includes all hollow parts that are affected by the conversion, whether it's a Tripod part or an OEM part which has been cut open.

Bottom finished




Put the right side wheelarch and both wheels back on the vehicle.

Upholstery




Before placing the floor cover, use an airgun to blow all metal bits off the floor. Degrease afterwards. When the floor is perfectly clean, place the floor cover in correct position. Fix the rear half temporarily in place. For example, by placing something heavy on the rear half.

Upholstery




Fold the front of the floor cover back. Be sure not to fold too sharp to prevent an uneven surface. Using a glue gun spray the first half of the floor and floor cover. Let it dry for 10 - 20 minutes before attaching the floor mat to ensure proper adhesion.

Upholstery



Fold the back of the floor cover to the front. Be sure not to fold too sharp to prevent an uneven surface. Using a glue gun, spray the rear half of the floor and floor cover. Let it dry for 10 - 20 minutes before attaching the floor mat to the floor to ensure proper adhesion.

Upholstery



Be sure the floor cover has nice fitment, if not, cut where necessary.

Upholstery



Cut off any of the floor cover that might extend over this edge.

Make sure the floor has no gas bubbles.

Upholstery



200 mm

Cut the floor mat as shown.

Upholstery

Leave an edge about 5 cm up against the wheelarches. This will help getting a cleaner look once the interior panels are placed.

6827


Use a hole saw to make holes for the TriflexAir seat brackets.
ONLY in case of TriflexAir seats.

Spray the sides and the OEM floor mat with the glue gun. Place the upholstery and cut to size.


Floor LED install

In case of the floor LED lights, cut out the rectangle openings to make the LED lights fit.

Floor LED install




Floor LED install




Route the wires all the way to the front opening.
Have the connectors at the beginning of the openings.

Floor LED install



Connect the wires to the LED lights.
Press the LED lights into the holes in the side of the lowered floor.

Floor LED install




Finish the upholstery by covering up these surfaces.

The LED floor lights are installed on both sides in the same way.

3-point belt stalks

Before installing, Take the bracket off, rotate the stalk off, remount on the bracket so it's positioned as shown.



Bag #21626 / #21627

NO.	QTY	PART	DESCRIPTION
1	2	1256	Hex bolt M10x30 8.8
2	2	173	Washer M10 8.8
3	2	5756	M10 bolt cap


Install the stalks.

3-point belt stalks



20Nm

Front retractors




Mount the front retractor.
Connect the wires to the retractors.

Bag #21626



NO.	QTY	PART	DESCRIPTION
1	2	1256	Hex bolt M10x30 8.8
2	2	173	Washer M10 8.8
3	2	5756	Bolt cap M10



Front retractors




54Nm

54Nm






Finishing




Cut along the markings.

Finishing



Install the rear sill, keep the middle part.
Remove the ridges on the bottom of the sill if they prevent good fitment.

Finishing




Bag #20999

Install the rear cover.

NO.	QTY	PART	DESCRIPTION
1	2	5795	Socket countersunk head screw M12x40 10.9
2	2	5562	Triplock, floor part


Finishing



Be sure the rear cover is mounted straight. These holes should be centered to the holes in the crossmember.


120Nm

Finishing




From the ramp locks, take out the top screw on both sides.

Finishing




On the inside there is blue foil on the perpex. Remove this foil!

Finishing




NO.	QTY	PART	DESCRIPTION
1	1	11114	Bumpstop D20 - H12 - M6x20
2	1	11276	Hex thin nut M6 A2-70
3	1	8606	Large washer
4	1	8870	Socket button head screw M6x12 A2-70

Finishing




Parking sensors



Be sure to cut the wires at different lengths. Keep enough wire on the sensor and on the wiring loom to prevent problems when connecting the tripod wires.

Take the parking sensor wiring out of the rear bumper. Cut off the middle 2 sensors.

Parking sensors



Remove the marked rubbers at the bottom of the tailgate to open up 2 oval holes.

Parking sensors




Pull the cables through these holes.
Apply a grommet (Partno. 3540) in the oval holes.

Keep the cables on the inside.

Route the cables through the grommet connecting the tailgate.

Route the cables down the inside of the D-pillar.

Route the cables through the rubber at the bottom of the D-pillar.




Connect the middle 2 sensors to the extension cables.
Purple -> left
Brown -> right

Parking sensors




Connect the purple extension wire to the sensor on the left.



Connect the brown extension wire to the sensor on the right.


Connect the extension wires to where the sensors have been cut off as shown.

Parking sensors



Cut 15mm off the bumper strip corner pieces. Both the left and right piece.

Parking sensors



Mount OEM bolt.


1

Bag #19892

Install the plastic rear bumper corner strips as shown.


NO.	QTY	PART	DESCRIPTION
1	1	1459	Pop rivet 4,8x12,7 alu/st

Parking sensors




Place the rear bumper on the vehicle. Mark the rear bumper 15mm on the outside of the upright edge on the back of the crossmember.

Parking sensors




Cut the mid section. While cutting make sure not to cut inside the markings to allow more precise modification of the middle part later on. Also be sure the ramp has well enough space to open and close.

Parking sensors



Keep the rear bumper on the vehicle.

Parking sensors



Route the parking sensor wiring loom across the front side of the rear crossmember. Place the corner sensors back in the bumper. Wrap the cables in water resistant tape for proper protection against short circuit.


Interior panels



Cut out the rubber around the magnetic switch in order for it to work properly.


Place the OEM weather strip.

Interior panels



Cut the weatherstrip at the edge of the lip on the rear crossmember as shown. Do this on both sides.

Interior panels




Place the cover as shown, mark the contour 10mm to the inside.

Interior panels




Interior panels




Install the cover.

Interior panels




Place both the rear lower panels. Make these holes only on the right side.


Interior panels



3-point belt install




3-point belt install



20Nm

3-point belt install



3-point belt top part

3

2

1

Bag #21626

Mount the 3-point belt top part.


NO.	QTY	PART	DESCRIPTION
1	1	4162	Hex bolt UNF 7/16 x 1 3/4"
2	1	1387	Washer 7/16 UNF
3	1	20132	Spacer di12/D30+21/L16

3-point belt install




Torque the bolt.

Rear bumper support




Place the bumper bracket and mark the marked holes on the bumper corner.

Rear bumper support




Drill the marked holes and thread them M6.

Rear bumper support




Rear bumper support



Drill through the bumper and the bracket, thread M6.



Rear bumper support







Mount the top of the bumper to the bracket as shown. The previous steps about this bracket can be exactly replicated on the other side.

Bag #19892

NO.	QTY	PART	DESCRIPTION
1	1	10387	Nylon button head screw M6x16 PA6








If the ramp is not centered correctly adjust it by loosening these 2 screws, 2 full turns maximum!



Ramp




Ramp




With the ramp in upright position, turn the torsion spring as far counter clockwise as possible. Like shown.



Ramp



Ramp



Ramp

20838

Only with 2 tailgate doors.


Place the template on the right side of the ramp.
Align the top edge and the right edge as shown.

Ramp

Only with 2 tailgate doors.

Mark the hole in the template on the ramp.


Ramp



Only with 2 tailgate doors.

Take the template away and drill Ø8 mm.

Ramp




Only with 2 tailgate doors.

Lightly mount the bracket.
The bracket should be able
to rotate on the bolt

Bag #20835

NO.	QTY.	PART	DESCRIPTION
1	1	10013	Socket countersunk head screw M8x25 A2-70
2	1	7475	Large Washer M8 A2-70
3	1	64	Torque nut M8 8.8


Ramp



Only with 2 tailgate doors.

Mark the hole as shown.


Ramp



Only with 2 tailgate doors.

Rotate the bracket as shown.
Drill the marked hole $\text{\O}9$ mm.

Ramp




Bag #20835

Only with 2 tailgate doors.

NO.	QTY.	PART	DESCRIPTION
1	1	10124	Countersunk head rivet nut M6x16 8.8

Ramp




Bag #20835

Only with 2 tailgate doors.

NO.	QTY.	PART	DESCRIPTION
1	1	11655	Socket button head FLANGE screw M6x20 A2-70


Ramp



NO.	QTY.	PART	DESCRIPTION
1	2	16066	Socket button head FLANGE screw M8x16 A2-70
2	2	8081	Washer M8 A2-70
3	2	64	Torque nut M8 8.8



Only with 2 tailgate doors.

Ramp



Only with 2 tailgate doors.

Check if the position is correct to properly open and close the tailgate. The tailgate must be able to open and close perfectly. Torque the bolts when the tailgate catch is properly adjusted.




3rd row TriflexAir seats




Remove the rear cover of the TriflexAIR seat, then remove the swivel plate.

3rd row TriflexAir seats




Remove the bottom of the swivel plate by taking the marked bolts out. If one of the bolts doesn't come loose, follow the next step.

3rd row TriflexAir seats




If one of the bolts won't come loose, try the other bolt and use the bottom part to rotate the stuck bolt to open the swivel plate as shown.

3rd row TriflexAir seats




Remove the thin plate from the bottom and take out the alignment plate.

3rd row TriflexAir seats



In the marked slots there are 2 strips, take these out.

3rd row TriflexAir seats





Install the new lock strips.

Bag #21515

NO.	QTY.	PART	DESCRIPTION
1	2	20262	TriflexAIR lock strip


3rd row TriflexAir seats



Be sure to NOT use the original alignment plate.

Reassemble the TriflexAir swivel plate with the NEW alignment plate.


3rd row TriflexAir seats




Bag #21491

NO.	QTY.	PART	DESCRIPTION
1	2	11382	Socket countersunk head screw M10x35 010.9
2	1	18082	Socket countersunk head screw M10x45 010.9
3	1	20026	Socket countersunk head screw M10x70 012.9
4	4	-	Triflex shim
5	1	9254	Socket countersunk head screw M10x30 010.9
6	1	11954	Socket countersunk head screw M10x50 010.9
7	4	173	Washer M10 8.8
8	4	11339	Hex flange nut M10 10.9

3rd row TriflexAir seats




3rd row TriflexAir seats



Cut the outside bottom corner as shown to make more room for the bent locking pawl.


3rd row TriflexAir seats



Bend the locking pawl down so that it clears all the covers when (un)locking and can make the full turn.

Be sure the area underneath the seat stays flat.

3rd row TriflexAir seats




Install the swivel plate on the TriflexAir seat bracket. If the seat isn't stable, add shims diagonally to mount the seat tighter.

Bag #21491 & #21515

NO.	QTY	PART	DESCRIPTION
1	1	11382	Socket countersunk head screw M10x35 10.9
2	1	21550	Socket countersunk head screw M10x90 12.9 black
3	1	11339	Socket countersunk head screw M10 10.9


3rd row TriflexAir seats



Bag #21491 & #21515

NO.	QTY	PART	DESCRIPTION
1	1	21550	Socket countersunk head screw M10x90 12.9
2	1	11382	Socket countersunk head screw M10x35 10.9

3rd row TriflexAir seats



Bag #21491


NO.	QTY	PART	DESCRIPTION
1	1	17752	Socket button head screw M5x14 A2-70
2	1	10205	Torque nut M5 A2-70

3rd row TriflexAir seats



Make sure the (un)locking mechanism functions properly and does not hook on any of the covers. Also make sure there is absolutely no play.

3rd row TriflexAir seats



Mount the rear cover back on the seat.

Taillights



Reinstall the taillights.

Rear bumper



Replace the gas struts with the new ones.

Rear bumper

Position correctly by inserting the pin on the template into this hole.


20007

Place the templates on the tailgate as shown.

Rear bumper


Mark the holes according to the bracket.

Rear bumper



Mark the holes according to the bracket.

Rear bumper




Drill the holes Ø8mm.

Rear bumper

This part can be bent upward so it's easier to position correctly.

19868

19870



Place the brackets on the inside of the tailgate over the drilled holes.


Rear bumper

BLUE
Loctite
#241

19838

2

1




Bag #19892


Mount the bumper bracket.

NO.	QTY	PART	DESCRIPTION
1	4	4652	Socket countersunk head screw M6x12 8.8
2	4	10815	Socket button head screw M6x12 8.8

Rear bumper




Rear bumper



On the middle part of the bumper.
Make the top inside edge smooth by removing any clip/bracket.


Rear bumper



Modify the middle part of the bumper so the edges are perfectly straight. Use the measurement as reference. Check the width by placing the bumper in front of the ramp. The bumper should be at least equally wide or slightly wider than the ramp cover. Be sure not to cut off too much to prevent bad fitment to the side bumpers.


Rear bumper

Try testfitting the bumper caps.
If it doesn't fit, this corner can
be flattened for better fitment.



Cut off a bit from all 4 corners so the covers fit nicely. Check by placing the covers.

Rear bumper




On the top of the bumper, modify the edge as shown, starting from the corners. This must be done for fitment on the rear bumper bracket. Do this left and right.

Rear bumper



Close the ends of the middle bumper with the bumper covers. Make sure the bumper is at least as wide as the ramp cover. Check this by holding the bumper in front of the ramp.

Rear bumper




Drill the holes $\varnothing 5\text{mm}$ on both sides as shown.
Fasten the bumper covers with rivets.


Bag #19892

NO.	QTY	PART	DESCRIPTION
1	8	4832	Pop rivet PVC 5 mm

Rear bumper




Rear bumper




Position the middle bumper on the bracket.
Plug in the parking sensors.

Rear bumper




Center the middle bumper on the bracket.

Rear bumper



Use the marked edge (ramp cover) as reference to center the middle bumper.

Rear bumper




Drill and thread 2x M6 through the bumper and the middle bumper bracket. If the bumper and the bracket are not touching, use washers to adjust the fitment. Fasten with bolts.


Bag #19892

NO.	QTY	PART	DESCRIPTION
1	2	10387	Nylon button head screw M6x16 PA6


Rear bumper



Rear bumper




Rear bumper



Place the bumper covers on the outer bumpers.
Drill the holes through the outer bumpers Ø5 mm.
Do this on both sides.


Rear bumper



Bag #19892


NO.	QTY	PART	DESCRIPTION
1	4	4832	Pop rivet PVC 5 mm

Emergency exit




Get the tailgate cover.

Emergency exit



Drill a Ø5mm hole in the most right support ridge.
Drill as straight through the ridge as possible.


Emergency exit



On the second ridge, drill a $\text{\O}5\text{mm}$ hole through the corner, through the panel. Be sure to drill as flat as possible as explained in the next view.

Emergency exit


Be careful not to damage the outside of the cover with the rotating bits on the drill.



While drilling, rotate the drill up to be as flat as possible. The hole must be as straight as possible.


Drill through the other side of the hole.

Emergency exit




Use a $\text{Ø}10\text{mm}$ drill to carve a slight extra bit of space in the opening for the tailgate lock. Drill where marked.

Emergency exit




Use the latch to determine its position. Place the latch on the right side of the tailgate cover. Make sure it will be mounted on the flat surface, not on the radius. Mark and drill a $\text{Ø}25\text{mm}$ hole where the cable mounts will extend through the hole.

Emergency exit




Remove the sides of the bottom black housing as shown.

Emergency exit




Take the inner cable out of the outer cable.
Screw the cable adjuster all the way into the upper hole.

Emergency exit



Secure with the nut.



Emergency exit




Install the latch on the cover with screws.

Bag #20843

NO.	QTY.	PART	DESCRIPTION
1	2	7657	Parker 4,8x19 verzonkenkop - A2




Emergency exit



Insert the inner cable into the outer cable.

Emergency exit



Insert the rod through the drilled holes as shown. Use a clamp to fix the rod to the inner cable. Make sure rod 20844 can slide without friction.

Bag #20843

NO.	QTY.	PART	DESCRIPTION
1	1	8835	Steel wire clamp 3mm

Emergency exit



Reinstall the tailgate panel.

Emergency exit



Insert the rod through the plastic latch in the tailgate lock.

Emergency exit

8895



Apply the screw nipple to the end of the rod to secure the emergency exit system. After completing this step, check if the system works correctly. Also check if the door indicator light functions properly during a test drive. If not release the tension of the cable.

Tailgate cover protection

1




In case of the clearview ramp, check where the ramp edges will make contact with the tailgate. Determine the correct position for the bumpstops. Drill and thread $\text{\O}6\text{mm}$. Install the bumpstops on both sides.

Bag #19895

NO.	QTY	PART	DESCRIPTION
1	1	16163	Bumpstop 5mm

Rear retractors




Bag #20999


Install the Triplock mounting parts on the rear retractor. Left and right are installed the same.

NO.	QTY	PART	DESCRIPTION
1	1	21613	Socket button head screw M12x35 10.9
2	2	294	Washer M12 8.8
3	1	20997	Angled bracket
4	1	18139	Torque nut M12 10.9
5	1	21011	Bolt cap M12

Rear retractors



Rear retractors




Bag #20999


NO.	QTY	PART	DESCRIPTION
1	1	21006	Socket countersunk head screw M12x30 10.9
2	1	20996	Triplock floor part
3	1	294	Washer M12 8.8
4	1	18139	Torque nut M12 10.9
5	1	21011	Bolt cap M12

Install the Triplock mounting parts on the rear retractor. Left and right are installed the same.

Rear retractors




Rear retractors




Install the rear retractors.

End of conversion



After the conversion is finished and the final check has been executed, Apply cavity protection coating to ALL bolts that are affected by the conversion. This includes: New bolts/OEM bolts/reused bolts.

End of conversion



Vaccuum the interior.

Tightening torques

	Zinc coated steel		Stainless steel	
	8.8	10.9	70	80
M4	3 Nm	4 Nm	2,5 Nm	3,5 Nm
M5	6 Nm	8 Nm	5 Nm	7 Nm
M6	10 Nm	14 Nm	8 Nm	11 Nm
M8	26 Nm	37 Nm	21 Nm	28 Nm
M10	54 Nm	75 Nm	44 Nm	58 Nm
M12	85 Nm	120 Nm	71 Nm	88 Nm
M12x1,5	89 Nm	125 Nm		
M14x1,5	150 Nm	205 Nm		
M16x1,5	220 Nm	310 Nm		
UNF				
		Grade 5		
7/16 CTSK Triplock		60 Nm		
7/16 seat belt		35 Nm		
Blind rivet nut				
	Steel	Aluminium	Stainless	
M5	5	4	4,5	
M6	9	6	7,5	
M8	22	18	20	
M10	48	28	41	

Always use these torques unless else is mentioned in the manual.

Tighten wheel bolts with the manufacturer's instructions.

Bolts with special attention are:

- Suspension
- Seats
- Seat belts

Tools and chemicals used by Tripod



Sealant gun



Click clamp pliers



Rivet gun, used for Magna-lok rivets





Crimping tool, for electrical connections



Heat gun, for bending plastic fuel lines



Step drill, for drilling variable diameter holes



Brake bleeder



Cleaning solvent, type 1



Cleaning solvent, type 2

D



Contact spray glue, for the upholstery



Sikaflex 221 sealant, for sealing seams




Zink spray primer, for uncoated metal.
First layer



1K epoxy primer
Second layer



Satin black spray paint
Third layer




Tectyl Terotex HV450, used in all hollow parts of the body, with the appropriate spray gun



Tectyl Terotex 2000, used for protection of the underside of the chassis and lowered floor, with the appropriate spray gun



Tectyl ML, for parts where you can't use Tectyl Terotex HV450



Tectyl Bodysafe, for parts where you can't use Tectyl Terotex 2000



WHEELCHAIR ACCESSIBLE VEHICLES

If you want to receive product information (safety/data sheets) of the products mentioned in this chapter, please contact support@tripodmobility.com

Disclaimer; descriptions are based on the information available during publication and are valid until further notice.
We cannot guarantee the correctness and completeness of the information given and therefore do not accept liability.



www.tripodmobility.com • Collseweg 10, 5674 TR Nuenen, the Netherlands
T +31(0)40 283 6442 • F +31(0)40 283 6245 • E info@tripodmobility.com